



- 1. ClassicBond EPDM Membrane
- 2. ClassicBond Decking Adhesive (See Notes)
- 3. ClassicBond Bonding Adhesive
- 4. Suitable thermal insulation, thickness determined by U-value
- 5. Vapour Control Layer (VCL)
- 6. Structural decking
- 7. Plastisol flashing (flashing to be mechanically fixed into upstand at max 500mm spacings) or code 4 lead by others
- 8. Thermal insulation to detail where applicable
- 9. ClassicBond Lap Sealant or suitable sealant by others
- 10. Reinforced Universal Secure Strip (RUSS)
- 11. Suitable Fastener with 50mm Seam Plate

Diagram 2

Notes:  
 1. This detail was prepared to serve as a guideline representing typical detailing conditions and illustrate the correct application of ClassicBond products only. It may be necessary to modify this detail in whole or part in accordance with specific project conditions, design or requirements.  
 2. Acrylic Decking Adhesive is for timber substrates only, all other suitable surfaces use ClassicBond Bonding Adhesive.  
 3. If 75mm field seam turns up through angle change install PS cover patch using 225mm uncured EPDM tape.  
 4. Alternate fixing detail for RUSS as shown in diagram 2.  
 5. The maximum inside angle change before RUSS is required should be no more than 9.5°.

	Title WALL FLASHING DETAIL		Drawn MFO		Checked DW		Approved DW		Scale 1: 4@A4		Date 03.02.14			
	Product CB-W-1		Status PRODUCTION											
			A		03.02.14		PRODUCTION		Issue		Drawing No: CB/W/1		Rev: B	
			Rev		Date		Comments							