


Notes:

1. This detail was prepared to serve as a guideline representing typical detailing conditions and illustrate the correct application of ClassicBond PRO products only. It may be necessary to modify this detail in whole or part in accordance with specific project conditions, design or requirements.
2. If 75mm field seam turns up through angle change install Pressure Sensitive cover patch using 225mm PS Elastoform Tape.
3. Dependant on width of the bottom of box gutter, the Bonding Adhesive (3) can be carried along the base of the box gutter or use ClassicBond Decking Adhesive



www.ClassicBond.co.uk

Title BOX GUTTER			Drawn MFO	Checked DW	Approved DW	Scale 1: 4@A4	Date 13.09.12
Product DP-BG-1			Status PRODUCTION				
B	02.04.14	Text updated	Drawing No: DP/BG/1				Rev: B
A	13.09.12	PRODUCTION Issue					
Rev	Date	Comments					