

PS WALKWAY PADS

ClassicBond Pressure-Sensitive Walkway Pads are designed to protect the membrane in those areas exposed to repetitive foot traffic.

INTENDED USE

1. Walkways must be installed at all traffic concentration points (i.e. roof hatches, access doors, rooftop ladders, etc.) regardless of traffic frequency.
2. Walkways must also be installed if regular maintenance (once a month or more) is necessary to service rooftop equipment.

FEATURES & BENEFITS

- Excellent tear and puncture resistance
- UV resistant
- Slip resistant

APPLICATION*

1. The entire surface where the PS Moulded Walkway Pad will be applied must be clean. The adhesive on the back of the PS Moulded Walkway Pad will not adhere to dusted or dirty surfaces. Any residual contamination will be detrimental to the bond strength of the adhesive.

2. Remove all foreign material.

a. Remove excess mica dust by brushing or wiping with a clean, dry.

b. The use of Weathered Membrane Cleaner may be necessary. This process is essential on membrane that has been exposed for several weeks. Note: Permeation-resistant gloves (that meet ANSI/ISEA 105-2005) are required for hand protection when cleaners or primers are being used.

c. Allow the membrane to dry thoroughly before proceeding.

3. Application of ClassicBond Primer:

a. Standard Membrane - Apply the primer with a clean rag. Scrub the area of the membrane where the PS Moulded Walkway Pad is to be applied in a circular motion to achieve a thin, even coating on the membrane. The properly cleaned/primed area will be uniform in colour without streaks and free of globs or puddles.

b. Pre-Kleened™ Membrane - Roller-apply the primer to the membrane with a short pile paint roller. The coated area will be free of globs or puddles. Note: The use of excessive amounts of primer will not significantly enhance the adhesion of the PS Moulded Walkway Pad to the ClassicBond membrane. Use only the amount necessary to obtain 100% coverage of the area where the PS Moulded Walkway Pad will be applied.

4. Allow the primer to properly flash off until it does not transfer to a dry finger touch. Install the PS Moulded Walkway Pads as soon as the primer flashes off to minimise potential dust contamination and promote adhesion in colder weather.

5. Allow 25mm between PS Walkway Pads. Discontinue Walkways over seams, allowing a minimum 25mm.

[Review ClassicBond specifications and details for complete installation information.](#)

PRESSURE SENSITIVE WALKWAY PADS

PRECAUTIONS

1. The product is to be used as a walkway only and is not designed as a substitute for ballast.
2. PS Moulded Walkway Pads cannot be installed within 3 m of the roof perimeter or on projects that exceed 15 m in height for Design "B" (Ballasted) systems. Concrete pavers may be used in these areas.
3. When installing walkways in conjunction with ballast, avoid the entrapment of small ballast below walkways. Also, avoid excessive application of primer on ballasted systems installed over EPS insulation.

Before using this product please ensure that you have been supplied with and have read carefully the following information:

1. The product labels
2. ClassicBond PS Walkway Pads Safety Data Sheet

PROPERTIES AND CHARACTERISTICS

Colour: Black
Pad Thickness: 9mm +/- 10%
Performance requirements density (pct): 70
Tensile Strength (psi) ASTM D 412 Unaged: 500
Tear resistance (ppi) ASTM D 624 Unaged: 250
Size: 750mm x 750mm